Elvox 887 B (DIGIBUS)







Terminals

3

5

6

Other Models :887B Digi Bus, 887C Digit2video, 887D Digi 2 Wire

IMPORTANT NOTE:

- 1) Before replacing the handset make note of the wires to each terminal on the existing unit (an easy way is to cut each core off leaving a piece of the insulation in place with colour visible) twist unused cores together (so you know they are not used, <u>do not</u> short them out).
- 2) Some older systems will have cable with one coloured core and a solid white core in this case mark each core with a marker or tape.
- 3) Some systems may have <u>loop on wiring</u>, you will have 2 cables into your handset (make sure any joins remain, as these may be serving other flats on the system).

© 2010 www.intercomsrus.com

1- SIMPLE CONDOMINIAL INSTALLATION WITH INTERPHONES EQUIPPED WITH INTERNAL DECODING. Ref diagram P3062R4

