ISM 2404/NIDTC (Council Systems)







Terminals

S +
2 DM
3 SI
4 PO
P1
CC

Replaces original 2404/NIDT

To open handset undo bottom screw then move lid down first to avoid breaking upper clips.

IMPORTANT NOTE:

- 1) Before replacing the handset make note of the wires to each terminal on the existing unit (an easy way is to cut each core off leaving a piece of the insulation in place with colour visible) twist unused cores together (so you know they are not used, do not short them out).
- 2) Some older systems will have cable with one coloured core and a solid white core in this case mark each core with a marker or tape.
- 3) Some systems may have <u>loop on wiring</u>, you will have 2 cables into your handset (make sure any joins remain, as these may be serving other flats on the system).

© 2010 www.intercomsrus.com