Techniphone TN-5HK







Terminals

- 1 Speech Out
- 2 Speech In
- 3 Common
- 5 Lock
- V Call
- LL Aux Button (Volt Free)

IMPORTANT NOTE :


1) Before replacing the handset make note of the wires to each terminal on the existing unit (an easy way is to cut each core off leaving a piece of the insulation in place with colour visible) twist unused cores together (so you know they are not used, <u>do not</u> short them out).

2) Some older systems will have cable with one coloured core and a solid white core in this case mark each core with a marker or tape.


3) Some systems may have <u>loop on wiring</u>, you will have 2 cables into your handset (make sure any joins remain, as these may be serving other flats on the system).

© 2010 www.intercomsrus.com


WIRING DIAGRAM




WIRING DIAGRAM Techniphone (1 Way Mini Kit) 4+n



WIRING DIAGRAM Techniphone (2 Way Mini Kit) 4+n



WIRING DIAGRAM Techniphone (3 Way Mini Kit) 4+n



WIRING DIAGRAM Techniphone 2 Entrance Switcher Mini Kit Wiring

