Bitron AN0002





Terminals

- C7 Call (electronic)
- 11 Call (AC Buzzer)
- 1 Speech In (Speaker)
- 2 Speech Out (Mic)
- 9 Lock
- 6 Common

IMPORTANT NOTE :


1) Before replacing the handset make note of the wires to each terminal on the existing unit (an easy way is to cut each core off leaving a piece of the insulation in place with colour visible) twist unused cores together (so you know they are not used, <u>do not</u> short them out).

2) Some older systems will have cable with one coloured core and a solid white core in this case mark each core with a marker or tape.

3) Some systems may have <u>loop on wiring</u>, you will have 2 cables into your handset (make sure any joins remain, as these may be serving other flats on the system).

© 2010 www.intercomsrus.com

Wiring Diagram Bitron Domular Classic 1 Entrance



Wiring Diagram Bitron Domular Classic with 2 Entrances

